



WD PURESTONE Care and Maintenance

Daily Care and Maintenance

Use a mild dish soap (such as Dawn® Ultra Original Liquid Dish Soap) or Windex® Multi-Surface Cleaner for daily cleaning. You may also use a 50/50 mix of vinegar and water. Be sure to use a non-abrasive cloth when cleaning to avoid dulling the surface.

After cleaning, be sure to rinse the surface with warm water and dry with a clean cotton cloth or paper towel.

Stubborn, Dried-On Stains and Spills

Use a light or non-abrasive cleanser by first applying it to a clean cotton cloth or paper towel, not directly onto the surface. Clean using a circular motion on the affected area; rinse and dry thoroughly. The following cleansers are recommended for use to remove dried-on spills from your surface:

- Soft Scrub® Gel with Bleach
- Bar Keepers Friend® Cleanser (powder or cream)
- Simple Green® Extreme Clean
- Simple Green® Lemon Fresh
- Windex® Multi-Surface Cleaner
- Windex® Multi-Surface Cleaner with Vinegar

When using Bar Keepers Friend® Cleanser powder, apply it first to a damp, clean cloth or paper towel. Then, squeeze together several times to form a paste before applying to your surface.

To remove any adhered material, such as food, gum, or nail polish, start by scraping away the excess material with a plastic putty knife. Then, clean any remaining residue with a damp cloth.

Kitchen Tools and Knife Marks

Never cut directly on your surface, as this will result in residual metal knife marks. These are not scratches and can be removed using the same steps for treating stubborn stains and spills. The use of cutting boards is strongly recommended.

Resistance to Heat

Your surface is heat resistant, not heat proof. We strongly recommend using trivets or hot plates to protect your surface from damage caused by sudden temperature changes, especially when using cooking units such as electric frying pans or crock pots. Never place hot cookware directly onto your surface.

Chemicals and Harsh Cleaners

Avoid exposing your surface to any of the following:

- Oven, grill, toilet bowl, furniture, and drain cleaners
- Paint and floor strippers
- Tarnish removers
- Oil-based soaps and cleansers
- Battery acid and other caustic substances

Immediately rinse the area with water if your surface is exposed to any of these types of products.

Prolonged exposure may cause discoloration or damage to your surface.

No Sealer Required

Do not apply sealers or polishes to your surface. They are not necessary. Over time, these can make your surface appear dull and/or inconsistent.

CONTACT US

 +1 (800) 532-0434  www.web-don.com  info@web-don.com

CHARLOTTE, NC | RALEIGH, NC | WILMINGTON, NC | WINSTON-SALEM, NC | COLUMBIA, SC | PINEY FLATS, TN